


Powerbank W1086 10,000 mAh

User Manual

1. LED indicators
2. Output USB-A 1
3. Input USB-C
4. Output USB-A 2
5. Power button
6. Input Micro-USB




Specification

Brand	Blue Star
Model	W1086
Capacity	10 000 mAh (37 Wh)
Total output	5 V/2 A
USB-C	5 V/2 A
Micro-USB	5 V/2 A
USB-A 1	5 V/1 A
USB-A 2	5 V/2 A
USB-C + USB-A	5 V/2 A
Cable (included)	USB-A to USB-C (25 cm)

Battery level

Press the power button to check the current battery status via LED indicators.

Battery indicator	Battery level
1 light	20%
2 lights	50%
3 lights	circa 80%
4 lights	100%




Powerbank charging

The powerbank can be charged using a USB cable. Connect it to a power source and to the Micro-USB or USB-C port on the powerbank at the same time.

Powerbank W1086 10,000 mAh

Instrukcja obsługi

1. Diody LED
2. Port wyjściowy USB-A 1
3. Port wejściowy USB-C
4. Port wyjściowy USB-A 2
5. Przycisk zasilania
6. Port wejściowy Micro-USB




Specyfikacja

Marka	Blue Star
Model	W1086
Pojemność	10 000 mAh (37 Wh)
Maksymalna moc	5 V/2 A
USB-C	5 V/2 A
Micro-USB	5 V/2 A
USB-A 1	5 V/1 A
USB-A 2	5 V/2 A
USB-C + USB-A	5 V/2 A
Kabel (dołączony)	USB-A do USB-C (25 cm)

Stan baterii

Wciśnij przycisk zasilania, aby sprawdzić aktualny stan baterii za pomocą diod LED.

Wskaźnik zasilania	Stan baterii
1 dioda	20%
2 diody	50%
3 diody	ok. 80%
4 diody	100%



Ladowanie powerbanka

Powerbanka można naładować, wykorzystując przewód USB. Podłącz go jednocześnie do źródła zasilania i do portu Micro-USB lub USB-C w powerbanku.